

ELECTRIC FIREPLACE

/ MODEL: GM-3 SF SERIES

USER MANUAL



CONTENTS

SAFETY & PRE-INSTALLATION

Important Safety Information!	02
Preparation	03

01

PARTS, DIMENSIONS & INSTALLATION

Parts & Hardware	05
Specification And Dimension	05
Installation And Assembly	06


02

SAFE OPERATION & MAINTENANCE

Warning	16
Care And Maintenance	18

03

SAFETY & PRE-INSTALLATION



Welcome, and thank you for choosing our product. Before installation, let's walk through the essential safety notes and a few simple preparations. Taking a moment here ensures everything goes smoothly later.

IMPORTANT SAFETY INFORMATION!

01 / WARNING

- Read all instructions before using this heater!
- This heater is hot when in use. To avoid burns, DO NOT let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front of the heater, and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- DO NOT operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and /or repair.
- DO NOT run power cord under carpeting. DO NOT cover power cord with throw rugs, runners, or similar coverings. DO NOT route power cord under furniture or appliances. Arrange power cord away from traffic area, and where it will not be tripped over.

02 / WARNING

- Connect to properly grounded outlets ONLY.
- DO NOT insert or allow foreign objects to enter any ventilation or exhaust openings, as this may cause electric shock or fire, or damage the heater.
- To prevent a possible fire, DO NOT block air intakes or exhaust in any manner. Doing so could cause a fire. DO NOT use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. DO NOT use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- ALWAYS plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- DO NOT place the heater near a bed because objects such as pillows or blankets can fall off the bed and be ignited by the heater.
- NEVER use this heater in bathrooms, laundry rooms, or any other location where the heater could fall into a bathtub or pool, become damp or come in contact with water.


- AVOID FIRE! Regularly inspect all air vents to make sure they are free from dust, lint, or other blockage. Unplug the unit and clean with a vacuum ONLY. DO NOT rinse or get wet.
- ALWAYS mount to wall bracket before use. DO NOT set on the floor, or other surface, to use.
- NEVER use a wall mount bracket from another manufacturer.
- This product is not intended to be a primary heat source. It is for supplemental heat only.
- INDOOR use only! NEVER use this heater outdoors! Doing so may result in electric shock!
- Risk of electric shock! DO NOT OPEN! No user-serviceable parts inside!
- ALWAYS turn this heater off before unplugging it from the outlet.
- ALWAYS disconnect this unit from the power supply before performing any assembly or cleaning, or before relocating the electric fireplace.
- NEVER leave this heater unattended. ALWAYS unplug this heater when not in use.
- ALWAYS store this heater in a dry location. NEVER use the fireplace if it has become wet.
- NEVER plug this heater into an outlet that is old, cracked, or has any loose wires or connections. Plugging this heater into a faulty outlet could result in electric arcing within the outlet that could cause the outlet to overheat or catch fire.
- ALWAYS check your heater cord and plug connections with each use!
 - i) MAKE SURE the plug fits tight in the outlet! Faulty wall outlet connections or loose plugs can cause the outlet to overheat.
 - ii) Heaters draw more current than small appliances. Overheating may occur even if it has not occurred with the use of other appliances.
 - iii) During use check frequently to see if the plug outlet or face plate is HOT!
 - iv) If the outlet or face plate is HOT, discontinue use immediately and have a qualified electrician inspect and/or replace the faulty outlets.

PREPARATION

This product includes a GLASS panel! Always use extreme caution when handing glass. Failure to do so could result in personal injury or property damage.

Remove all parts and hardware from the carton and place them on a clean, soft, dry surface. Parts and assembly steps are grounded for wall-hanging or recessing use. Check the parts list to make sure nothing is missing. Dispose of packaging materials properly. Please recycle whenever possible. You will need the following tools (not included): Phillips screwdriver; stud finder; level; tape measure; electric drill; 1/4" wood drill bit, hammer.

PARTS, DIMENSIONS & INSTALLATION



Now that you've reviewed the safety guidance and prepared the workspace, you're ready to move on. The next section introduces all included parts, product dimensions, and the step-by-step installation process. Follow along at your own pace for a smooth setup.

PARTS & HARDWARE

A Fireplace




B 4X10MM Screw
X12



C 4X25MM Screw
X4



D Fasten Bracke
X4



E Crystal Stone
one package



F Carbon Log
one box





G Rubber Mat
X4




H Remote Control




SPECIFICATION AND DIMENSION



Front View



Side View



Top View



Remote Control

INSTALLATION AND ASSEMBLY

01/ FREESTANDING INSTALLATION

- 1 Remove four pcs of black screws out of appliance, please see Figure (A)




Figure (A)

2 Take and pull up the front tempered glass out off appliance. See Figure (B)




Figure (B)

3 Take the logs' carbon box out off appliance, See Figure (C)




Figure (C)

4 Lay the heater on the floor or a soft place, install the rubber mats "G" with 4pcs screws "B" (4x10mm) as provided see Figure(D)




Figure (D)

5 Put the crystal stone "E" and carbon log "F" to bed. see Figure(E)




Figure (E)

6 Insert and restore the tempered glass to original location. see Figure(F)




Figure (F)

7 Use original 4x8mm screws to fasten the tempered glass. see Figure(G)





Figure (G)

Your appliance is capable of three unique installation configurations: three-sided, two-sided, and single-sided.

- **Three-Sided Viewing Installation**


Appliance is fully recessed into the wall with both sides open: Front, left, and right side views.



For illustrative purposes only.

- **Two-Sided Viewing Installation**


Appliance is fully recessed into the wall with one side open: Front view and left/right side view, depending on desired open/closed sides.



For illustrative purposes only.

- **Single-Sided Viewing Installation**

Appliance is fully recessed into the wall: Left and right side views are covered.



For illustrative purposes only.

02 / RECESSED TO WALL INSTALLATION

(fasten from front)




Image is for illustrative purposes only.

NOTICE 1

1. Appliance is NOT load-bearing. Carefully consider weight of finishing materials when constructing rough framing.
2. Ensure installation complies with all local building codes and requirements.
3. All viewing options (single-sided, two-sided [left and right], and three-sided) use the same framing dimensions.

1

Attach the fasten bracket "D" to the heater with two 8*10mm screws, see Figure (H)





Figure (H)

2

Put the fireplace to mantel hole. Use 4pcs of 4x25mm screws "C" to fasten the bracket at front.



03 / RECESSED TO WALL INSTALLATION

(fixed at both sides)




Image is for illustrativepurposes only.

1 Attach the fasten bracket "D" to the heater (at both sides) with two 8*10mm screws, see Figure (I)






Figure (I)

2 Put the fireplace to mantel hole. Use 4pcs of 4x25mm screws "C" to fasten the bracket at front .



SAFE OPERATION & MAINTENANCE



Great progress—your installation is complete or nearly there. The next section will show you how to operate the product safely and make the most of its features. You'll also find cleaning and maintenance tips to keep it performing reliably.

WARNING


- Turn off the appliance completely and let cool before servicing. Only a qualified service person should service and repair this electric appliance.
- Read and understand this entire owner's manual, including all safety information, before plugging in or using this product. Failure to do so could result in electric shock, fire, serious injury, or death.

01 / POWER

- Plug the power cord into a 220-240V Volt 7 Amp outlet (see IMPORTANT SAFETY INFORMATION on Pages 2 and 3). Make sure the outlet is in good condition and that the plug is not loose. NEVER exceed the maximum amperage for the circuit. DO NOT plug other appliances into the same circuit.

02 / METHODS OF OPERATION

- This electric fireplace can be operated either by the switches located on the top right hand side of the fire or by supplied remote control.



TOUCH PANEL/REMOTE CONTROL OPERATION		
BUTTON	FUNCTION	ACTION&INDICATION
 POWER	ON: Enables control panel functions and remote control. Turn on flame effect. OFF: Disables control panel functions and remote control. Turn off flame effect.	1.Press once. Indicator light turns on. Power turns on. All functions enabled. 2.Press again, power turn off.
 COLOR	COLOR button: Makes the color flame effect changing.	1.Press once. Flame color effect gets changing. 2.Press again until desired setting is reached.
 FLAME	FLAME button: 1.Makes flame effect dimmer and brighter. 2.Change the flame color(On fireplace control panel)	1.Press once. Flame brightness effect gets changing. 2.Press again. Until desired setting is reached.
 HEATER	HEATER button: Turn heater on and off. NOTE: To prevent overheating, the heater fan will blow out cool air for 30 seconds after the heater turn off.	1.Press once. Indicator lights up and show "L". Low heater turns on and blows warm air. 2.Press again. Indicator lights up and show "H". High heaters turns on and blows hot air. 3.Press again. Indicator show "00". The fan blows cool air for 30 seconds to allow heater to cool down, then turns off.
 TEMP.	TEMPERATURE button: Control temperature settings to choose temperature as desired. Setting range from (62F to 82F / 17C to 27C). Long press to switch between Celsius or Fahrenheit	1.Press once. Indicator light turn on. Temperature is set to 62F/17C. 2.Press again until desired setting is reached. LED display show setting.
 TIMER	TIMER button: Control timer settings to turn off fireplace at selected time. Settings range from 0 hours,1hours, to 8 hours.	1.Press once. Indicator light turn on. Temperature is set to hours. 2.Press again until desired setting is reached. LED display show setting.

NOTICE 1

When the heater is first turned on, a slight odor may be present. This is normal and should not occur again unless the heater is not used for a long period of time.

NOTICE 2

To improve operation, aim the remote control at the front of the fireplace. DO NOT press the buttons too quickly. Give the unit time to respond to each command.

03 / TEMPERATURE LIMITING CONTROL

This heater is equipped with a Temperature Limiting Control. Should the heater reach an unsafe temperature, the heater will automatically turn OFF. To reset:

- 1.Unplug the power cord from the outlet.
- 2.Turn the ON/OFF switch on the CONTROL PANEL to OFF. Wait 5 minutes.
- 3.Inspect the fireplace to make sure no vents are blocked, or clogged with dust or lint. If there are, use a vacuum to clean the vent areas.
- 4.With the POWER switch in the OFF position, plug the power cord back into the outlet.
- 5.If the problem continues, have your outlet and wiring inspected by a professional.

04 / REMOTE CONTROL BATTERY INFORMATION

Remote Control Battery Information

Remote control requires two AAA batteries

NEVER dispose of batteries in fire. Failure to observe this precaution may result in an explosion.

Dispose of batteries at your local hazardous material processing center.

CARE AND MAINTENANCE

01 / CLEANING

ALWAYS turn the heater OFF and unplug the power cord from the outlet before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in electric shock, fire, or personal injury.

NEVER immerse in water or spray with water. Doing so could result in electric shock, fire, or personal injury.

METAL:

- Buff using a soft cloth, slightly dampened with a citrus oil-based product.
- DO NOT use brass polish or household cleaners as these products will damage the metal trim.

GLASS:

- Use a good quality glass cleaner and dry thoroughly with a paper towel or lint-free cloth.

- NEVER use abrasive cleansers, liquid sprays, or any cleaner that could scratch the surface.

VENTS:

- Use a vacuum or duster to remove dust and dirt from the heater and vent areas.
- Clean the exterior of the fireplace with a slightly damp cloth or duster.

02 / MAINTENANCE

Risk of electric shock! DO NOT OPEN! No user-serviceable parts inside!

ALWAYS turn the heater OFF and unplug the power cord from the outlet before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in electric shock, fire, or personal injury.

ELECTRICAL AND MOVING PARTS:

- The fan motors are lubricated at the factory and will not require lubrication.
- Electrical components are integrated in the fireplace and are not serviceable by the consumer.

STORAGE:

- Store heater in a clean dry place when not in use.

WARNING! No other servicing should be performed by the consumer. Do not attempt to service the unit yourself.

03 / TROUBLESHOOTING

WARNING! Disconnected the appliance completely and let cool prior to any service. Only a qualified service person should service and repair this electric appliance.

PROBLEM	POSSIBLE CAUSE	SOLUTION
Fireplace turns off and will not turn on.	1.Fireplace has overheated and safety device has caused thermal switch to disconnect or home circuit breaker has opened.	1.Reset switch by turning main power off and waiting turning it back on or breaker circuit breaker.
Flame is not moving.	1.Loose wiring. 2.Flame motor defective. 3.Flame rod out of place	1.Inspect wiring for loose connections. 2.Call a qualified service technician to replace flame motor. 3.“Flame Rod” out of place due to rough transit/handling of the product. This issue can be corrected as simple as removing the glass, flipping the fireplace upside and down, removing a set of screws that are holding the bottom frame plate and placing the flame rod back into place.
Flame is not visible.	1.Wiring is loose.	1.Disconnect from power source and inspect wiring for loose connections and repair or replace if necessary. 2.Push the flame button to high.
Log set and /or is not glowing.	1.Wiring is loose. 2.Ember is off mode.	1.Disconnect from power source and inspect wiring for loose connections and repair or replace if necessary.
Remote control does not work.	1.Low batteries. 2.Not aiming control correctly. 3.Defective remote control and / or sensor.	1.Replace batteries in remote control. 2.Aim control at sensor located directly behind glass screen in center of unit just above logs.. 3.Replace remote control and/ or sensor.

HOWARM

You've reached the end of the guide. With proper use and regular care, the product will continue to deliver reliable performance and comfort for years to come. If you ever need assistance, our support team is always ready.
